


CHIP KEY CARD AIR

Article number:

MI-CKM3-0001-01AIR	ACCESS CARD
MI-CKM3-0006-01AIR	DECORATION CARD
MI-CKM3-0005-01AIR	SUPERVISOR CARD
MI-CKM3-0007-01AIR	MASTER CARD 1
MI-CKM3-0008-01AIR	MASTER CARD 2
MI-CKM3-0012-01AIR	PROGRAMMING CARD
MI-CKM3-0013-01AIR	ERASING CARD



ACCESS CARD print with legal disclaimer, white area for user name and photo printout.
 SUPERVISOR CARD print with legal disclaimer, white area for user name and photo printout.
 DECORATION CARD print with legal disclaimer, white area for user name and photo printout.
 MASTER CARD 1 print with legal disclaimer, white area for user name and photo printout.
 MASTER CARD 2 print with legal disclaimer, white area for user name and photo printout.
 PROGRAMMING CARD print with legal disclaimer, white area for user name and photo printout.
 ERASING CARD print with legal disclaimer, white area for user name and photo printout.



Reader Range

AIR2ONE Controller Internal/External Reader

5,0 cm*

* minimum value

Please read carefully the AIR2ONE User Guide Manual and find the different functionality of each card.

CHIP KEY RING AIR

Article number:

MI-CKM3-0002-01AIR	ACCESS KEYFOB
MI-CKM3-0002-01DAIR	DECORATION KEYFOB
MI-CKM3-0002-01SAIR	SUPERVISOR KEYFOB



Mifare 1K CHIP

ACCESS KEYFOB, Presenting the Access Key Fob at the AIR2ONE Internal/External Reader allows the salesperson to open the showcase.

Access Keys are neutral at delivery and must be programmed following the described procedure in AIR2ONE User Guide. Lost or stolen CHIP Keys must be reported to the management to avoid possible misuse.



Reader Range

AIR2ONE Controller Internal/External Reader

3,5 cm*

* minimum value